



DULYL B PPE DOFF Sheet

| Company: Division: Group: Date: Time: PPE DECONTAMINATION SAFETY (CHEMICAL/HAZMAT) Incident: | | | | | | Page # of Pages MERLENN® Operator System Use: Log all corrective action / mitigation activity in the MERLENN® Safety or Emergency Use Workflow for Biohazard or |
|---|---|------------------------|------------------|-----------------|------------------|---|
| Step 1 | In <u>Hot Zone</u> : Complete Decon Rinse; Seat Self with Feet in Bio Bag . DOFF Outer Gloves 1 and drop into Bag . | | | | | equivalent. MERLENN® Emergency |
| Step 2 | Assistant DOFFs SCBA Harness leaving Facepiece, Regulator, and Air Hose still attached & Air Flow still on. | | | | | |
| Step 3 | Assistant will use Chem Tape tabs and remove Chem Taped points. Responder DOFFs Hood, Boots into Bio Bag. | | | | | |
| Step 4 | DOFF Chem Tape on Facepiece and drops into Bio Bag. Peel back Suit Overlap, unzip suit, peel Suit from inside down into Bag. DOFF Gloves layer 2 into Bag. No Touch of Outside Suit | | | | | |
| Step 5/6 Step 7 | Move to <u>Cold Zone</u> . Maintain Air Flow, loosen SCBA Facepiece straps, push Facepiece away from face. Assistant will place SCBA Facepiece into new Bio Bag DOFF Inner Gloves layer 3 into Bio Bag, Step to Med Eval Station & Shower Immediately! | | | | | |
| | | | | | | |
| 1-D/RINSE (INIT) | 2-SCBA (INIT) | 3-HOOD/BOOTS (INIT) | 4-SUIT (INIT) | 5-AIR (INIT) | 6-FACE (INIT) | 7-INNER GLOVES/SHOWER (INIT & COMPLETE NAME) |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |