



LVL D PPE DOFF Sheet

Company: _____
Division: _____
Group: _____
Date: _____
Time: _____

PPE DECONTAMINATION SAFETY (BIOHAZARD, INFECTIOUS DISEASE)

Incident: _____

Page # _____ of _____ Pages

MERLENN® Operator System Use:

Log all corrective action / mitigation activity in the **MERLENN® Safety or Emergency**

Use Workflow for Biohazard or equivalent. **MERLENN® Emergency**

- Step 1** In ***Hot Zone*** Step into **Bio Bag** (trash liner) and DOFF **Outer Gloves** in **Glove** (layer 1). Drop into **Bag**
- Step 2/3/4** Using **Bleach Wipes** Wipe **Gloves** (layer 2) & **Gown Front**. Cut **Booties** and DOFF by sliding them off into **Bio Bag**.
- Step 4** Untie **Gown** and with any other **Contaminated Items** drop them in **Bio Bag**
- Step 5** DOFF **Face Shield** and or **Goggles** into new **Bio Bag**.
No Touch of Gown Front
- Step 6** Move to ***Cold Zone*** DOFF **Respirator** or **Mask** by **Bottom Strap** first **No Touch Respirator** or **Mask Front**. **Assistant** will place **Face Shield/Mask** into new **Bio Bag**.
- Step 7** DOFF **Inner Gloves** layer 3 into **Bio Bag**, Step to **Med Eval Station & Shower ASAP!**

1-GLOVES (SIGN)	2-WIPE (SIGN)	3-HOOD/GOWN (SIGN)	4-BOOTIES (SIGN)	5-FACE (SIGN)	6-MASK (SIGN)	7-HANDS & SHOWER (SIGN)